



Place your **mKaart** in front of the loading icon.



Select your connector (connector 1 or connector 2) by pressing the button next to the display.



Connect the cable into the selected connector.



Your car is now connected and charging starts automatically.



Charging is in progress, a green indicator light is on.



You may stop the process at any time by pressing «end of charge».